



*How to.....*

## **Repairing Asphalt Surfaces using SAKRETE Asphalt Repair**

Asphalt areas that have sunk, have wide cracks, or are damaged from gas and oil should be repaired.

**SAKRETE Asphalt Repair** is a cold patch mixture of blended asphalts and aggregates. Designed for repairing asphalt drives, walks, and parking areas. Repairs should be between 2" to 4" in depth and up to 4 square feet in surface area. The asphalt is poured into the repair area and compacted.

### **STEP 1: Preparation:**

Chisel out and remove all existing damaged asphalt to a depth of 2" to 4". Using a stiff broom or brush, remove all loose particles, mud, dust, grass, etc. Fill deeper holes with gravel to proper depth.

### **STEP 2: Application:**

Pour SAKRETE Asphalt Repair into hole and level about ½" higher than surrounding pavement. Thoroughly compact with a hand tamper. Compact deep holes in layers 2" or less. Newly repaired areas may normally be used after 3 to 7 days.

### **Tips for working with SAKRETE Asphalt Repair**

- 1) Compact in layers 2" or less.
- 2) In cold weather keep bag in a warm place at least 24 hours before using.
- 3) In warm weather hardening is prolonged.
- 4) The greater the compaction, the better the patch
- 5) When sealing follow manufacturer's directions.
- 6) Use proper safety equipment i.e. safety glasses, gloves, etc.

For additional information please refer to our Data sheets.



For more information and other projects, visit us at [www.king-products.com](http://www.king-products.com)